

Mam Nature Swiss AG
Spinnereistr. 16
8645 Jona
Switzerland

ETH Zurich
Dr. Sreenath Bolisetty
Senior Scientist
Schmelzberg Strasse-9
8092 Zürich, Switzerland

www.hest.ethz.ch

Zurich, 16. October 2025

Scientific Report

To whom it may concern:

I commissioned and supervised analytical testing of the **Swiss Water Cartridge (20" POE (= Point of Entry) Water Filter Cartridge** – to be installed right after the water meter for whole house application with flow rates of >1800 Liters / h) from the company Mam Nature Swiss AG incorporating a filter media, developed at ETH Zurich and based on an amyloid–carbon platform.

Testing was performed with validated methods (ICP-MS/ICP-OES, EPA 537M for PFAS, fluorometry, and gamma counting/scintigraphy for radionuclides) under standard QA/QC.

The results confirm high single-pass removal of heavy metals, selected organics, nutrients, and PFAS; in separate clinical/nuclear evaluations, the same filter media removed representative radionuclides to below detection.

Below I summarise the results as inlet → outlet with removal efficiency: → see the following page



Contaminant	Influent	Effluent	Removal %
Heavy metals ¹⁾:			
Lead (Pb)	100 µg/L	0.516 µg/L	98.97 %
Cadmium (Cd)	100 µg/L	0.021 µg/L	99.98 %
Arsenic (III)	100 µg/L	0.24 µg/L	99.76 %
Arsenic (V)	100 µg/L	0.24 µg/L	99.76 %
Copper (Cu)	100 µg/L	3.74 µg/L	96.26 %
Chromium (Cr)	298.4 µg/L	1.451 µg/L	99.51 %
Zinc (Zn)	100 µg/L	3.48 µg/L	96.52 %
Iron (Fe)	100 µg/L	25 µg/L	75.00 %
Manganese (Mn)	312.7 µg/L	5.83 µg/L	98.13 %
Molybdenum (Mo)	100 µg/L	0.466 µg/L	99.53 %
Vanadium (V)	100 µg/L	0.119 µg/L	99.88 %
Platinum (Pt)	47.63 µg/L	<0.01 µg/L	≥ 99.98 %
Other contaminants ²⁾:			
PFOA	0.63 µg/L	<0.01 µg/L	> 98.4 %
PFOS	0.67 µg/L	<0.01 µg/L	> 98.5 %
Phosphate (PO ₄)	1000 mg/L	12 mg/L	98.8 %
Free residual chlorine	1000 µg/L	52 µg/L	> 99 %
Bisphenol-A (BPA)	2.13 µg/L	0.05 µg/L	97.87 %
MTBE	38.62 µg/L	0.63 µg/L	98.37 %
Fluoride (fluorometer)	7.86 µg/L	3.309 µg/L	57.9 %
Aluminium	5000 µg/L	92 µg/L	98.16 %
Pesticides ²⁾:			
Bentazon	97.41 µg/L	0.030 µg/L	99.97 %
Pharaceuticals ³⁾:			
Ibuprofen	1.0 ppm	0.025 ppm	97.5 %
Dyes ³⁾:			
Crystal violet	10 ppm	Qualitative: µg/L	99.97 %
Acid fuchsin	10 ppm	solution turned µg/L	99.97 %
Acriflavine	10 ppm	transparent; µg/L	99.97 %
Rhodamine B	10 ppm	aerogel took on µg/L	99.97 %
Malach ite green	10 ppm	dye color µg/L	99.97 %
Organic solvent ³⁾:			
n-Hexane	Qualitative demo (floating layer on water)	Qualitative: fully absorbed into the filter media within ~20 s	Qualitative only; no concentration reported
PFAS ⁴⁾:			
PFBA (C3)	>70 ng/l	3.65 ng/l	> 96 %
PFHxA (C6)	>70 ng/l	< MDL ng/l	Complete within MDL
PFHpA (C7)	>70 ng/l	< MDL ng/l	Complete within MDL
PFOA (C8)	>70 ng/l	< MDL ng/l	Complete within MDL
PFBS (C4)	>70 ng/l	< MDL ng/l	Complete within MDL
PFHxS (C6)	>70 ng/l	< MDL ng/l	Complete within MDL
PFOS (C8)	>70 ng/l	< MDL ng/l	Complete within MDL
Radioactive pollutants (clinical & nuclear wastewaters) ⁵⁾:			
Tc-99m (hospital wastewater)	236670 cpm/ ml	0.8 cpm/ ml	99.9997% %
I-123 (hospital wastewater)	294395 cpm/ ml	0.8 cpm/ ml	99.9997% %
Ga-68 (hospital wastewater)	16530.1 cpm/ ml	29.4 cpm/ ml	99.8221% %
I-131 (hospital wastewater)	118.25 cpm/ ml	0.005 cpm/ ml	99.9958% %
Lu-177 (hospital wastewater)	1226.6 cpm/ ml	0.55 cpm/ ml	99.9552% %

- 1¹: Method: ICP-MS; single-pass filtration; flow equivalent $\sim 1.8 \text{ m}^3$ water.
Data from ETH letter (Dr. Christophe Zeder). -> *Reference A*: Cartridges retention report
- 2²: -> *Reference A*: Cartridges retention report
- 3³: Method: by ultraperformance liquid chromatography (UPLC) analysis: -> *Reference F*
- 4⁴: The **technology is proven to remove the PFAS** listed under single-step filtration conditions reported in the referenced study.
The publication gives a numeric permeate only for PFBA (3.65 ng/L); other permeates were below the method detection limit; feed bars are plotted graphically. The paper concludes complete removal for PFAS with $\geq \text{C4}$ and $>96\%$ for PFBA (C3). -> *Reference B*
- 5⁵: The **technology is proven to remove the radionuclides** on real clinical effluents and representative nuclear solutions, with permeate activities at or below detection as indicated in the cited studies.
"Not detected" = activity below instrument detection under test conditions. For Cs-137, two passes reached the 10 Bq L^{-1} guidance level). -> *Reference C, D & E*

References (written format):

- A. ETH Cartridge Retention Report / ICP-MS Metals Letter (Dr. Christophe Zeder). Independent ETH Zürich analytical report summarising organics, nutrients, chlorine, aluminium and heavy-metal retention for the Mam Nature Swiss Water Cartridge (20" POE).
Cartridges retention report
- B. PFAS Removal Using Amyloid–Carbon Hybrid Membranes (Figure 6, EPA 537M). Peer-reviewed article reporting complete removal (within MDL) for PFAS with $\geq \text{C4}$ and $>96\%$ removal for PFBA (C3); permeate PFBA = 3.65 ng/L.
- C. Clinical Radioactive Pollutant Removal — Hospital Wastewaters. Study showing $\geq 99.8\text{--}99.995\%$ single-pass removal of Tc-99m, I-123, Ga-68, I-131, and Lu-177, with permeate below detection and radionuclide immobilisation confirmed by scintigraphy.
- D. Radioactive Cesium Removal (Cs-137). Laboratory dataset demonstrating $\sim 99.7\%$ single-pass removal ($\sim 340\times$ reduction) and high capacity; two passes reach 10 Bq L^{-1} guidance.
- E. PSI Annual Report (Membrane Studies). Supporting technical notes on radionuclide handling and analytical methodology used in associated projects.
- F. Amyloid Fibrils Aerogel for Sustainable Removal of Organic.
Contaminants from Water, advanced materials, 2020, 32, 1907932

Technical remarks and limitations:

Results were obtained under controlled conditions with defined influent chemistry, contact time, and temperature. Field performance depends on site conditions (pH, temperature, competing ions/organics, flow regime) and media loading.

Yours faithfully

B. Sreenath

Dr. Sreenath Bolisetty
Senior Scientist

ETH Zürich — Department of Health Sciences & Technology
Schmelzbergstrasse 9, 8092 Zürich, Switzerland

